



a DE

Anschlüsse / Bestandteile	
a-1	2x blau (Impulskabel), potentialfrei Anschluß an den Tastereingang der anzusteuernden Komponente
a-2	schwarz + rot, 24V AC/DC Versorgung für den Empfänger
a-3	LED-Lämpchen Zeigt eingehende Funkimpulse durch Aufleuchten an
a-4	Antenne

b

Erlernung eines Handsenders:

- 1) Halten Sie den zu erlernenden Sender neben der Antenne direkt an das Empfängergehäuse
- 2) Drücken Sie kurz die zu erlernende Taste am Handsender - die LED leuchtet
- 3) Drücken Sie nochmals kurz die zu erlernende Handsendertaste - die LED erlischt

Der Handsender ist jetzt eingelernt und kann benutzt werden.

Löschen des Empfängerspeichers:

- 1) Nehmen Sie einen beliebigen, bereits eingelernten Handsender
- 2) Halten Sie den Sender neben der Antenne direkt an das Empfängergehäuse
- 3) Halten Sie die Handsendertaste so lange gedrückt, bis die LED erlischt

Der Empfängerspeicher ist jetzt komplett gelöscht (d.h. alle bisher gespeicherten Handsender wurden gelöscht!)

Maximale Anzahl zu erlernender Handsender: 16 Stück

a GB

Connections / Equipment	
a-1	2x blue (impulse-cables), floating connector. Connect these cables to the push-button connector of the device
a-2	black + red, 24V AC/DC power supply for the receiver
a-3	LED-lamp Indicates incoming impulses
a-4	Aerial

b

Programming a hand transmitter:

- 1) Hold the transmitter very close to the receivers' housing right beside the antenna
- 2) Press the hand transmitters' button shortly - the LED-lamp stays on
- 3) Press the hand transmitters' button once again - the LED-lamp goes off

The hand transmitter now is programmed into the receiver.

Clearing the receivers' memory:

- 1) Take any hand transmitter that was programmed into the receiver
- 2) Hold the transmitter very close to the receivers' housing right beside the antenna
- 3) Keep the hand transmitters' button pressed until the LED-lamp goes off

The receivers' memory is now completely cleared (this refers to all hand transmitters that were previously programmed).

Maximum quantity of hand transmitter per receiver: 16 units.